



(€





## **Model Number**

## OBG5000-R100-2EP-IO-0,3M-V1

Retroreflective sensor (glass) with fixed cable and M12 connector, 4-pin

## **Features**

- Miniature design with versatile mounting options
- Detects transparent objects, i.e., clear glass, PET and transparent films
- Two machines in one: clear object detection or reflection operating mode with long range
- High degree of protection IP69K
- IO-link interface for service and process data

# **Product information**


The R100 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.


The DuraBeam laser sensors are durable and can be used in the same way as a standard

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.

## **Dimensions**



# **Electrical connection**




## **Pinout**

Wire colors in accordance with EN 60947-5-2

(brown (white) (blue) (black) WH BU BK

# Indicators/operating means





| 1 | Teach-in button |
|---|-----------------|
|   |                 |

2 | Mode rotary switch

3 Operating indicator / dark on

4 Signal indicator

5 Operating indicator / light on

|  | normal |  |
|--|--------|--|

Mode I - 10 % contrast detection

Mode II - 18 % contrast detection

Mode III - 40 % contrast detection

٧ Switching type

Keylock

### **Accessories**

### V31-WM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

## V31-GM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

### REF-H85-2

Reflector, rectangular 84.5 mm x 84.5 mm, mounting holes

### REF-H50

Reflector, rectangular 51 mm x 61 mm, mounting holes, fixing strap

#### REF-H33

Reflector with screw fixing

### IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

### OFR-100/100

Reflective tape 100 mm x 100 mm

Other suitable accessories can be found at www.pepperl-fuchs.com

EMC Directive 2004/108/EC

Compliance with standards and directi-

approx. 17 g

EN 60947-5-2:2007 + A1:2012

0.3 m

ves


Cable length

Directive conformity


| Standard conformity        |                                                                            |
|----------------------------|----------------------------------------------------------------------------|
| Product standard           | EN 60947-5-2:2007 + A1:2012<br>IEC 60947-5-2:2007 + A1:2012                |
| Standards                  | UL 60947-5-2: 2014<br>IEC 61131-9:2013<br>EN 62471:2008<br>EN 61131-9:2013 |
| Approvals and certificates |                                                                            |

**UL** approval E87056, cULus Listed, class 2 power supply, type rating 1

# **Curves/Diagrams**



### Relative received light strength in switch position "N'



## **Settings**

### Teach-in:

267075-100019\_eng.xml

2016-03-22

Date of issue:

Release date: 2016-03-10 09:56

Use the rotary switch to select the required operating mode: Normal mode (N) or contrast level I – III.

To teach in a threshold or activate an operating mode, press the "TI" button until the yellow and green LEDs flash in phase (approx. 1 s).

Release the "TI" button. Teach-in starts.

Successful teach-in is indicated by alternating flashing (2.5 Hz) of the yellow and green LEDs. The sensor will now operate in the selected operating mode with the taught-in threshold.

An unsuccessful teach-in is indicated by rapidly alternating flashing (8 Hz) of the yellow and green LEDs. After an unsuccessful teach-in, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued.

Every taught-in switching threshold can be re-taught (overwritten) by pressing the "TI" button again.

Note: To ensure that the device functions reliably in Contrast mode, the device must be powered on at least 30 s before Teach-in.

Setting the Device to Maximum Sensitivity

Use the rotary switch to select the Normal mode (N) position.

Press the "TI" button for > 4 s. The yellow and green LEDs will go out.

Release the "TI" button.

The settings will be reset to maximum sensitivity. After successfully resetting, the yellow and green LEDs will flash alternately (2.5 Hz).

Switching between light on/dark on

Use the rotary switch to select the light on/dark on (L/D) position.

Press the "TI" button for > 1 s.

PEPPERL+FUCHS

The respective operating indicator LED (L/D) will illuminate green and the switching type will change.

To reset the switching type, press the "TI" button for > 4 s.

The respective operating indicator LED (L/D) will illuminate green and the operating indicator will be reset to the most recently active switching type.

## **Reset to Default Settings**

Use the rotary switch to select the O position.

Press the "TI" button for > 10 s. The yellow and the green LEDs will both switch off.

Release the "TI" button. The yellow LED is on.

After resetting, the sensor will operate with the following default settings:

- Normal mode (N)
- · Maximum sensitivity adjustment
- · Dark on
- Pin 2 (white core): antivalent switching output

**EPPERL+FUCHS**